


Operation Diagrams






- (1) Ramp-up time. Time from zero load voltage to full load voltage.
- (2) Ramp-down time. Time from full load voltage to zero load voltage.
- (3) Initial torque. % of the nominal torque at the start of the ramp-up function.



Dimensions (mm)



ES 400-3 and 12

Type selection (with recommended manual motor starters)

| | | | | Mo | | load cu | ırrent (| A) | | | |
|---------------------------------|-------------|--------------|-------------|-------------|------|----------|-------------|----------|----------|-----------|----------|
| | 0,1 0,16 | 0,16 0,25 | 0,25 0,4 | 0,4 0,63 | 0,63 | 1 1,6 | 1,16 2,5 | 2,5 4 | 4 6,3 | 6,3 10 | 10 16 |
| FANOX Manual motors starters | M-0,16 | M-025 | M-0,4 | M-0,63 | M-1 | M-1,6 | M-2,5 | M-4 | M-6,3 | M-10 | M-16 |
| Soft starter | | | | ES 400-3 | | | | | E: | 5 400-12 | |

Note: The specifications are subject to change without notice. 10/01

Soft starters



ES

protection & control



- The best solution for a soft start/stop for 3 phase inductive motors up to 5,3kW (400V).
- Potencial-free control input.
- Easy setting with 3 independent potenciometers
- Internal heatsink and bypass relay incorporated.
- · Compact housing for DIN rail assembly.

-Ramp-up time -Ramp-down time

-Initial torque

Mode of Operation

An electronic circuit comprising semiconductor components starts the motor without the use of contacts. Neither switching sparks nor contact erosion occur.

Only when the motor nominal voltage is reached the power semiconductor devices are bypassed by relay contacts. Thanks to this technology, the ES motor controllers are substantially longer lasting than conventional contactors.

Easy to install and control. The ES control can take place either from outside by means of a control signal, eg, a programmable controller, or directly via the power supply of the motor to be controlled.

Type selection

| ES 400-3 3 A | 400 Vac | 1,1 | 1,5 | 270 gr | 41803 |
|----------------|---------|-----|-----|--------|-------|
| ES 400-12 12 A | ±15% | 5,5 | 7,5 | 270 gr | 41812 |

| Input Specifications | (Control Input) | Output Specifications | |
|---|---|--|---|
| Control voltage U _c A1-A2: | 24 - 110 VAC/DC ±15%, | Utilization category | CA 53b integral bypassing of semiconductors |
| A1-A3: | 110 - 480 VAC ±15%, 5 mA | Overload current profile (overload relay trip class) | ES 400-3: 6/13 |
| Rated insulation voltage | 630 V rms Overvoltage cat. III (IEC 664) | | ES 400-12: 6/13 |
| Dielectric strenght Dielectric voltage Rated impulse withstand volt | 2 kV (rms) . 4 kV (1,2/50 μs) | | |

www.fanox.com fanox@fanox.com Tlf. +34 944711409 Fax +34 944710592 02/2012/D00

Supply Specifications

| Power supply Rated operational volt. (U e) trought terminals L1-L2-L3 Voltage interruption Dielectric voltage Rated impulse withstand volt. | Overvoltage Cat. III (IEC 664) (IEC 38) 400 Vac rms ±15% 50/60 Hz -5/+5 Hz ≤40 ms 2 kV (rms) 4 kV (1,2/50 µs) |
|--|---|
| Rated operational power supplied from | 5 VA L1-L2 |

Semiconductor Data

| Rated operational current | l^2t for fusing $t = 1 - 10$ ms | Ітѕм | dl/dt |
|---------------------------|-----------------------------------|--------|----------|
| 3 A | 72 A ² s | 120 Ap | 50 A/ μs |
| 12 A | 610 A ² s | 350 Ap | 50 A/ μs |

Mode of Operation


This motor controller is intended to be used to soft start/stop 3 phase squirrel cage induction motors and thereby reduce the stress or wear on gear and belt/chain drives and to give smooth operation of machines. Soft starting and/or stopping is achieved by controlling the motor voltage.

During running operation the semiconductor is bypassed by an internal electromechanical relay

General Specifications

| Accuracy Ramp-up | ≤ 0,5 s on min. 5,5-7,5 s on max.(ES400-3 and 12) |
|---|--|
| Ramp-down | ≤ 0,5 s on min. 6-10s on max.(ES400-3 and 12) |
| Initial torque | ±15% on max. (ES 400-3 and 12) < 5% on min. |
| EMC Inmunity | Electromagnetic Compatibility acc. to EN 50 082-2 |
| Environment Degree of protection Pollution degree Operating temperature Storage temperature | IP 20 3 -20 a +50 °C (-4 to +122 °F) -50 a +85 °C (-58 to +185 °F) |
| ES 400-3 y ES-400-12 Control and Line screw terminals Minimum Max. tightening torque | 2,5 mm ² , AVG 14 0,5 mm ² , AWG 20 0,6 Nm |
| Line screw terminals Minimum Max. tightening torque | 10 mm ² , or 2 x 6 mm ² AWG 6 or 2 x AWG 10 1 mm ² , AWG 16 2 Nm |

Functional Diagram



Display Information

| | ES400-3 | ES400-12 |
|-----------------|----------|----------|
| Power Supply | green | green |
| Ramp | yelow | yelow |
| Bypass relay on | ✓_ yelow | |

Settings

| | ES400-3 | ES400-12 |
|---|---------|----------|
| Initial torque (% of nominal torque) | 0-85% | 0-85% |
| Ramp-up time | 0,5-5 s | 0,5-5 s |
| Ramp-down time | 0,5-5 s | 0,5-5 s |

Applications

Changing from Direct ON Line start to soft start (Line controlled soft start) (Fig. 1)

Changing a Direct On Line start into a soft start is very simple with the ES soft starting relay:

- 1) Cut the cable to the motor and insert the ES relay.
- 2) Connect control input to two of the incoming lines. Set initial torque to minimum and ramp up and down to maximum.
- 3) Power up again, adjust the start torque so the motor starts turning immediatly after power is applied, and adjust ramp time to the appropriate value.

When C1 is operated, the motor controller will perform soft start of the motor. When C1 is switched off, the motor will stop, the motor controller will reset and after 0.5 s a new soft-start can be performed.

Please note that the controller does not insulate the motor from the mains. Contactor C1 is therefore needed as a service switch for the motor

Soft start and soft stop (Fig. 2)

When S1 is closed, soft start of the motor will be performed according to the setting of the ramp-up potentiometer and the setting of the initial torque potentiometer. When S1 is opened, soft stop will be performed according to the setting of the ramp-down potentiometer.

Fusing Considerations

The motor controller provides bypassing of the semiconductors during running operation. Therefore the semiconductors can only be damaged by short-circuit currents during ramp-up and rampdown function.

A 3-phase induction motor with correctly installed and adjusted overload protection does not short totally between lines or directly to earth as some other types of loads, e.g. heater bands. In a failing motor there will always be some part of the winding to limit the fault current. If the motor is installed in an environment where the supply to the motor cannot be damaged, the short-circuit protection can be considered to be acceptable if the controller is protected by a 3-pole thermal-magnetic overload relay.

If the risk of short-circuit of the motor cable, the soft starter or the load exists, then the soft starter must be protected by ultrafast fuses, e.g. for a 3 A type: Ferraz 660 gRB 10-10, for an 12 A type: Ferraz 660 gRB 10-25. Fuseholder type PST 10.

ES 400-12

5min 3min

1min

40s

20s

9s


5


3min

15min

50s

20s





Time between rampings

To prevent the semiconductors from overheating, a certain time between ramping should be allowed. The time between rampings depends on the motor current during ramping and ramp time.

| | | • | |
|-----|-----|----------|-------|
| | I | ES 400-3 | |
| | R | amp time | 9 |
| (A) | 1 | 2 | 5 |
| 8 | 15s | 30s | 15min |
| 5 | 12s | 20s | 60s |
| 2 | 10s | 20s | 50s |
| 9 | 8s | 12s | 30s |
| 6 | 5s | 9s | 25s |
| 3 | 2s | 5s | 20s |
| ,5 | 1s | 2s | 5s |

Note: Table is valid for ambient temperature 25°C. For higher ambient temperature add 5% per°C to values in the tables. The more shaded areas in the tables are for blocked rotor. Do not repeat rampings with blocked rotor.